

# Battery Charger Catalogue

Charger Models	Output Voltage	Output Current	AC Voltage/Frequency Input	Suit for Battery
P2012-A6	6.9V	2A	100~240V	6 Volt 2~12Ah
P2012-A12	13.8V	1.5A	100~240V	12 Volt 2~8Ah
G60-12A	13.8V	3.3A	100~240V	12 Volt 4~40Ah
A100-12	13.8V	5.0A	100~240V	12 Volt 10~60Ah
A100-24	27.6V	2.8A	100~240V	24 Volt 4~25Ah
A100-36	41.4V	1.8A	100~240V	36 Volt 4~15Ah
A100-48	55.2V	1.6A	100~240V	48 Volt 4~12Ah
G100-12A	13.8V	5.0A	100~240V	12 Volt 10~60Ah
G100-24A	27.6V	2.8A	100~240V	24 Volt 4~25Ah
G100-36A	41.4V	1.8A	100~240V	36 Volt 4~15Ah
G100-48A	55.2V	1.5A	100~240V	48 Volt 4~12Ah
A200CM-12	13.8V	12A	100 or 240V(defined when order)	12 Volt 10~100Ah
A200CM-24	27.6V	6.0A	100 or 240V(defined when order)	24 Volt 8~50Ah
A200CM-36	41.4V	4.5A	100 or 240V(defined when order)	36 Volt 8~50Ah

A200CM-48	55.2V	3.5A	100 or 240V(defined when order)	48 Volt 8~30Ah
A500CM-24	27.6V	15A	100 or 240V(defined when order)	24 Volt 20~150Ah
A500CM-36	41.4V	11A	100 or 240V(defined when order)	36 Volt 10~120Ah
A500CM-48	55.2V	8.0A	100 or 240V(defined when order)	48 Volt 10~60Ah
3PL0504S	4.2V	0.8A	100~240V	3.7 Volt (1Cells) 1~4Ah
3PL0508S	8.4V	0.6A	100~240V	7.4 Volt (2Cells) 1~3Ah
3PL0512S	12.6V	0.35A	100~240V	11.1 Volt (3Cells) 1~3Ah
P2012-L1	4.2V	2A	100~240V	3.7 Volt (1Cells) 2~14Ah
P2012-L2	8.4V	2.0A	100~240V	7.4 Volt (2Cells) 2~14Ah
P2012-L3	12.6V	1.5A	100~240V	11.1 Volt (3Cells) 2~14Ah
P2012-L4	16.8V	1.3A	100~240V	14.8 Volt (4Cells) 2~14Ah
G60-12L3	12.6V	3.3A	100~240V	11.1 Volt (3Cells) 4~15Ah
G60-12L4	16.8V	2.8A	100~240V	14.8 Volt (4Cells) 2~15Ah

G60-12L5	21V	2.5A	100~240V	18.5 Volt (5Cells) 2~10Ah
L100-12	16.8V	5A	100~240V	14.8 Volt (4Cells) 4~25Ah
L100-24	29.4V	2.8A	100~240V	26 Volt (7Cells) 2~15Ah
L100-36	42V	2A	100~240V	37 Volt (10Cells) 2~15Ah
L100-48	58.8V	1.5A	100~240V	48 Volt (13Cells) 2~10Ah
G100-12L	16.8V	4.5A	100~240V	14.8 Volt (4Cells) 4~25Ah
G100-24L	29.4V	2.8A	100~240V	26 Volt (7Cells) 2~15Ah
G100-36L	42V	1.8A	100~240V	37 Volt (10Cells) 2~12Ah
G100-48L	54.6V	1.5A	100~240V	48 Volt (13Cells) 2~10Ah
L200CM-12	16.8V	12A	120 or 240V (defined when order)	14.8 Volt (4Cells) 10~100A h
L200CM-24	29.4V	6A	120 or 240V (defined when order)	26 Volt (7Cells) 8~50Ah

L200CM-36	42V	4.5A	120 or 240V (defined when order)	37 Volt (10Cells) 8~50Ah
L200CM-48	58.8V	3.5A	120 or 240V (defined when order)	48 Volt (13Cells) 8~30Ah
L500CM-24	29.4V	15A	120 or 240V (defined when order)	26 Volt (7Cells) 10~120A h
L500CM-36	42V	12A	120 or 240V (defined when order)	37 Volt (10Cells) 10~100 Ah
L500CM-48	54.6V	9A	120 or 240V (defined when order)	48 Volt (13Cells) 10~80A h
3P10- A1007	6.9V	1.2A	100~240V	6 Volt 2~6Ah
3P10- A1015	13.8V	0.8A	100~240V	12 Volt 1~4Ah
3PN0508S	6.4V	0.6A	worldwide AC 100~240V	3.6~4.8 Volt (3~4Cells) 1~4Ah
3PN0512S	9.6V	0.4A	worldwide AC 100~240V	4.8~7.2 Volt (4~6Cells) 1~3Ah
3PN0520S	16V	0.35A	worldwide AC 100~240V	8.4~12 Volt (7~10Cells) 1~2A h
P2012-N4	6.4V	2A	worldwide AC 100~240V	3.6~4.8 Volt (3~4Cells) 2~10A h

P2012-N6	9.6V	2A	worldwide AC 100~240V	6~7.2 Volt (5~6Cells) 2~10A h
P2012-N10	16V	1.5A	worldwide AC 100~240V	8.4~12 Volt (7~10Cells) 2~8A h
3PN3020M P	16V	0.9A&1.8AA	Worldwide AC 100~240V	7.2~12 Volt (6~10Cells) 2~10 Ah
N100-24	32V	2.8A	Worldwide AC 100~240V	24 Volt (20Cells) 4~20Ah
N100-36	48V	1.8A	Worldwide AC 100~240V	36 Volt (30Cells) 2~15Ah
N100-48	64V	1.5A	Worldwide AC 100~240V	48 Volt (40Cells) 2~8Ah
BG1-A6			6V	6 Volt
BG1-A12			12V	12 Volt
BG1-A24			24V	24 Volt
BG1-A36			36V	36 Volt
BG1-A48			48V	48 Volt
BG1-L2			7.4V	7.4 Volt (2Cells)
BG1-L3			11.1V	11.1 Volt (3Cells)
BG1-L4			14.8V	14.8 Volt (4Cells)
BG1-N4			4.8V	4.8 Volt (4Cells)
BG1-N5			6V	6 Volt (5Cells)
BG1-N6			7.2V	7.2 Volt (6Cells)
BG1-N10			12V	12 Volt (10Cells)

BG1-N20			24V	24 Volt (20Cells)
BG1-N30			36V	36 Volt (30Cells)
BG1-N40			48V	48 Volt (40Cells)
L0504SF	3.6V	0.8A	100~240V	3.2 Volt (1Cells) 1~4Ah
L0508SF	7.2V	0.6A	100~240V	6.4 Volt (2Cells) 1~3Ah
L0512SF	10.8V	0.35A	100~240V	9.6 Volt (3Cells) 1~3Ah
P2012-F2	7.2V	2.0A	100~240V	6.4 Volt (2Cells) 2~8Ah
P2012-F3	10.8V	1.5A	100~240V	9.6 Volt (3Cells) 2~6Ah
P2012-F4	14.4V	1.3A	100~240V	12.8 Volt (4Cells) 2~6Ah
G60-12F3	10.8V	3.3A	100~240V	9.6 Volt (3Cells) 4~15Ah
G60-12F4	14.4V	3.3A	100~240V	12.8 Volt (4Cells) 2~15Ah
G60-12F5	18.0V	2.0A	100~240V	16 Volt (5Cells) 2~10Ah
G60-12F6	21.6V	2.0A	100~240V	19.2 Volt (6Cells) 2~10Ah
L100-12F	14.1V	5.0A	100~240V	12.8 Volt (4Cells) 4~25Ah

L100-24F	28.8V	2.8A	100~240V	25.6 Volt (8Cells) 2~15Ah
L100-36F	43.2V	1.8A	100~240V	38.4 Volt (12Cells) 2~12Ah
L100-48F	54.6V	1.5A	100~240V	51.2 Volt (16Cells) 2~10Ah
G100-12F	14.4V	5A	100~240V	12.8 Volt (4Cells) 4~25Ah
G100-24F	28.8V	2.8A	100~240V	25.6 Volt (8Cells) 2~15Ah
G100-36F	43.2V	1.8A	100~240V	38.4 Volt (12Cells) 2~12Ah
G100-48F	54V	1.7A	100~240V	51.2 Volt (16Cells) 2~10Ah
L200CM-12F	14.4V	12A	120 or 240V (defined when order)	12.8 Volt (4Cells) 10~100Ah
L200CM-24F	29.4V	6.0A	120 or 240V (defined when order)	25.6 Volt (8Cells) 8~50Ah
L200CM-36F	43.8V	5.0A	120 or 240V (defined when order)	38.4 Volt (12Cells) 8~50Ah
L200CM-48F	54.8V	4.0A	120 or 240V (defined when order)	51.2 Volt (16Cells) 8~30Ah

L500CM-24F	28.8V	15.0A	100 or 240V (defined when order)	25.6 Volt (8Cells) 10~120A h
L500CM-36F	43.2V	12.0A	100 or 240V (defined when order)	38.4 Volt (12Cells) 10~100 Ah
L500CM-48F	54V	9A	100 or 240V (defined when order)	51.2 Volt (16Cells) 10~80A h
3PA5015R	14.8V	3.3A	100~240V	12 Volt 4~90Ah
3PL1004	4.2V	1.7A	100~240Vac 50/60Hz	3.6~3.7 Volt (1Cells) 1.8~12A h
3PL1008	8.4V	1.2A	100~240Vac 50/60Hz	7.4 Volt (2Cells) 1.2~9Ah
3PL1012	12.6V	0.9A	100~240Vac 50/60Hz	11.1 Volt (3Cells) 0.8~6.4A h
3PL1016	16.8V	0.7A	100~240Vac 50/60Hz	14.8 Volt (4Cells) 0.6~4.8A h
3PN1012	9.6V	1.2A	100~240Vac 50/60Hz	4.8~7.2 Volt (4~6Cells) 1.6~8. 0Ah

Email: [sales@abtcharger.com](mailto:sales@abtcharger.com)